

## SINCRO RD2 DIGITAL AVR FOR HB MODELS

Reference: AVR DIGITALE HB



RD2 Digital AVR (mounted on the alternator instead of the analogic AVR) for HB models.